



1. In the Menu/Settings/ “System Settings” and go on the “System Mode” function and select the “Operation” option:



2. In the same menu, go on the “Auto start menu” and select the “QTV ONLINETV” option:



3. Then once you enter to the “QTV ONLINETV (STALKER)” with your portal, you will not be able to exit, every time you Turn OFF the box and Turn ON it will go automatically to the “QTV ONLINETV”.

4. The only way to exit from the “QTV ONLINE TV (STALKER)” is make a Force Update with a special software, the steps are:

a. Download those special software:

i. **Qviart OG:**

<https://mega.nz/file/FPIChZ4B#dif8vqVgPxfGpk2lu9rHYLjF3kUjO4F26Y7zA4BHkI8>

ii. **Qviart OG 4K:**

https://mega.nz/file/sfYgAZZA#rZAilxJP5UNUcBraqAumxLI9xJHdY9sBVx_zgmVc5yY

iii. **Qviart OG2 4K:**

https://mega.nz/file/hPgQWQAI#ucCmLt6fgPQu_piPHpu1twJu_TUPlO_9EtxkOeEnLgA


iv. **Qviart OG2:**

https://mega.nz/file/AWxzXYYb#fhfA_RIX7qZE96NtgmnpPOFW2SamkcBfu7NQqER6drE

b. Once the download is done, unzip the “.zip” file and you will see it will create a folder with the same name.


c. Enter to that folder and you will see a file with the name “**auto.mugg**”.


d. Copy that “**auto.mugg**” file in the root of the USB stick:



e. Turn OFF the Qviart receiver, input the USB (with the “**auto.mugg**” file in the root) and Turn ON the Qviart receiver.

f. Then after the booting image, you will see how receiver automatically start to loading and updating the new software:





- d. Once the software has updated (you can check in the “Firmware Update” menu, the “SW Version” shows 3.00.00).
- e. This special software has only the function of make the Force Update, you should not use for anything else, so once this special software has updated you should install the latest version released (1.00....).